



SERVICE BULLETIN

No. 577

Piper Aircraft Corporation

Lock Haven, Pennsylvania, U.S.A.

"DOA SO-1 Approved"

May 1, 1978

S

Subject: Single Mask Oxygen System Turbo Arrow III

Models Affected: PA-28R-201T Turbo Arrow III

Serial Numbers Affected: 28R-7703001 to 28R-7803280 Inclusive

NOTE

This Service Bulletin is applicable to only those aircraft that have the optional oxygen system installed.

Compliance Time: Within the next ten (10) hours of aircraft operation.

Purpose:

The present optional oxygen system as offered on the Turbo Arrow III, includes four (4) each masks and two (2) each dual outlet adapters. Should one (1) or three (3) persons wish to utilize the system, the unused mask unnecessarily draws oxygen from the system.

To gain maximum utilization of the system when an odd number of persons are using the system, a single oxygen mask kit is being made available.

Instructions:

Modify one of the dual oxygen mask systems into a single or dual system using the adapters and instructions furnished with the kit listed below.

Material Required:

One (1) each per affected aircraft, Modification Oxygen System Kit, Piper part number 763 808V.

Availability of Parts:

Your Piper Field Service Facility.

Effectivity Date:

This Service Release is effective upon receipt.

Summary:

Please contact your Piper Field Service Facility to make arrangements for compliance with this Service Release in accordance with the provisions of Compliance Time, above. Reimbursement for above referenced modification material is available through your Piper Field Service Facility in accordance with their respective material allowance credit application procedure.